

## Grab Bar Installation

If you are planning to add grab bars, support blocking (2 x 4 or 2 x 6) should be added during framing as the wall panels and substrate material will not support the use of the grab bar. Failure to do this will cause the grab bars to come loose and could cause breakage or cracking of the panels. **THIS TYPE OF BREAKAGE IS NOT COVERED UNDER WARRANTY**

Predrill all holes through the wall panels where grab bars are to be installed.

Do not overtighten mounting screws, the wall panel can easily crack from overtightening screws.