



Commercial Bath Solutions

Accessory Shelf Installation with Wood Blocking

Important Information

If installing an Accessory Shelf, wood screws and barrel anchors are required when **BLOCKING** is present.

NOTE: All wall panels need to be installed and seams sealed with color matched silicone in the location where you are installing the Accessory Shelf prior to installation of the shelf.

Tools/Materials Required

- Two Barrel Anchors and two stainless steel wood screws
- 3/16" Drill Bit
- Drill
- Measuring tape
- Pencil
- 100% color matching silicone
- Clean dry rags
- #2 Phillips head screwdriver
- Acetone

INSTALLING ACCESSORY SHELF WHERE WOOD BLOCKING IS INSTALLED:

- Measure hole location on back side of Accessory Shelf and transfer these dimensions to the wall panel in the corner of the tub/shower enclosure where the Accessory Shelf will be located.
- 3/16" hole must be pre-drilled into the panel and drywall but not into the blocking. **THESE HOLES MUST BE PRECISE.**
- Install the steel barrel support as per instructions found within the package.
- Clean panel and back side of the Accessory Shelf.
- Apply 100% clear silicone to the entire back perimeter of the Accessory Shelf, using a minimum 1/4" bead of silicone. **NOTE (This step is very crucial and cannot be skipped. The barrel anchors are NOT designed to support the Accessory Shelf alone).**
- Apply silicone in the holes of the shelf.
- Slide the Accessory Shelf over the barrel and press firmly into the wall. **(Clean up squeeze-out of excess silicone).**
- Apply color matching silicone around perimeter of the Accessory Shelf to seal the Accessory Shelf to the wall panel. The seal should go around the entire perimeter of the Accessory Shelf, even apply to the underside of the Accessory Shelf as well.

DISCLAIMER NOTICE:

If the prescribed method of installation is not followed precisely then the Accessory Shelf may detach from the wall and cause damage to the panels and the walls. If the Accessory Shelf detaches, physical injury to the occupant of the shower may occur. MPL Corporation **WILL NOT** be liable for any damage to person or property due to incorrect installation.

The Accessory Shelf is to remain in place for a minimum of 48 hours to allow the silicone adhesive to cure. Absolutely NO weight is to be applied during the first 48 hours as this will weaken the silicone bond. If the Accessory Shelf is used before the required 48 hours, **ALL WARRANTIES WILL BE VOIDED.**

ANY MODIFICATION TO THE ACCESSORY SHELF ITSELF WILL VOID THE WARRANTY. THE PARTY MAKING AND/OR AUTHORIZING THE MODIFICATION WILL BE LIABLE FOR ANY AND ALL DAMAGES.

FOR ANY QUESTION OR COMMENTS, PLEASE CONTACT MPL COMPANY:

PHONE: 317-835-9000

WEBSITE: mplcompany.net

ADDRESS: P.O. BOX 220 or 203 North Edgerton St Fairland, IN 46126