



Installation Instructions for MPL Company Shower Niches



MATERIALS NEEDED:

- Torpedo level
- Silicone (100%) and caulk gun
- Acetone
- Clean, dry rags
- Pencil

Once the location of the niche is located, make sure to mark on the drywall wall. Make sure to lay out level and plumb lines on your drywall wall. Confirm that there are no studs or blocking in the wall by cutting out the drywall in the area where the niche is going. Also, be careful to not cut through the wall in the room behind the wall. You should make the size of this hole about 1" smaller than the outside dimensions of the niche. The hole in the panel should only be cut after the drywall has been cut to ensure there are no obstructions in the way.

When ready to install the niche, clean the back of the edges of the niche with a clean rag and acetone. Using the torpedo level, hold the niche in the hole and level the niche. Mark on the panel with your pencil to be used during installation. Use the silicone to adhere the niche to the panel. Using the reference lines on the wall to keep the niche level. Clean the pencil marks you made earlier with acetone. Then silicone around the edge of the niche.