


MPL[®] Company

Commercial Bath Solutions

15", 27", and 30" Footrest: Installation Instructions for Areas Without Wood Blocking.

Important Information

The following information is applicable for installing 15", 27", and 30" footrest into an area that does not have wood blocking. This is the recommended method of installation if there is no wood blocking wall.



Items needed:

- Set of 3 Anchors
- 13/16" drill bit, for drilling holes
- 3/16" drill bit
- Drill; for drilling holes
- Measuring tape
- Pencil
- Refer to Toilet & Bath Accessory Matrix for color and finish
- Cloths to clean footrest and panels
- 100% clear silicone for adhering the footrest to the wall
- #2 Phillips head screwdriver to tighten screws into footrest
- Cleaning solution

INSTALLING THE FOOTREST WITHOUT WOOD BLOCKING:

- Before installing the panels, verify that the studs will not interfere with the anchors. If the stud interferes, **STOP** and request blocking to be installed in the walls.
- Measure the locations of the slots on the back side of the footrest and transfer these dimensions to the panels in the corner of the shower/tub enclosure where the footrest is to be installed.
- 3/16" drill bit to drill pilot hole.
- A 13/16" pilot hole must be drilled into the and through the substrate. To use the anchor, these holes need to be precise.
- Install the anchor as per instructions which are located within the package, being sure to leave approximately 1" of the truss head on the screw sticking out. **NOTE: (The screws will be tightened after the footrest is placed on to the wall).**

- Clean the panel and footrest with surface cleaner.
- Apply 100% silicone to the entire back perimeter of the footrest, using a minimum ¼" bead of silicone. **(This step is very crucial and cannot be skipped. The screws are not designed to stand alone. The silicone adhesive is a necessary product in the installation of the footrest).**
- Slide the footrest over truss head screws and press firmly into place.
- Using a #2 Phillips head screwdriver, hand tighten the truss head screws until snug, and movement stops. **(DO NOT OVER TIGHTEN as this may crack wall surround and/or footrest).**
- Once the truss head screws have been tightened, try to move the footrest by applying pressure with your hands. If there is any movement re-tighten the screws until movement stops.
- Apply color matching silicone around the perimeter of the footrest to seal the footrest to the panels. The seal should go around the entire perimeter of the footrest, even applied to the underside of the footrest.

ANY MODIFICATION TO THE FOOTREST ITSELF WILL VOID THE WARRANTY. THE PARTY MAKING AND/OR AUTHORIZING THE MODIFICATION WILL BE LIABLE FOR ANY AND ALL DAMAGES.

DISCLAIMER NOTICE:

If the prescribed method of installation is not followed precisely then the footrest may detach from the wall and cause damage to the panels and the walls. If the footrest detaches, physical injury to the occupant of the shower may occur. MPL Company **WILL NOT** be liable for any damage to person or property due to incorrect installation.

FOR ANY QUESTION OR COMMENTS FEEL FREE TO CONTACT MPL:

PHONE: 317-835-9000

WEBSITE: mplcompany.net

ADDRESS: P.O. BOX 220 OR 203 North Edgerton St Fairland, IN 46126